











EziStage Safe Operating Instructions

1		<p>SECOND HEIGHT SETTING Undo the locking pins located on all four corners of the outer chrome extendable crossbar legs.</p>	5		<p>Do not leave the stage unattended in a half-open position. Place your foot in the centre of the extended chrome outer leg, and gently push downwards.</p>
2		<p>Slide the leg extensions down. Re-insert the locking pins to lock the leg into the extended position. Do not lower stage wing yet. Repeat leg extension for other side of stage.</p>	6		<p>Your stage will now be in the open position. Do not attempt to move or reposition the stage until both wings are down and The D legs are ratcheted together securely as in step 7 below.</p>
3		<p>Remove the locking pins holding the lower "D-Legs". Open the D-Legs outward.</p>	7		<p>Use ratchet straps to link each pair of opposite D-Legs. You may now reposition the stage safely.</p>
4		<p>Re-pin the D-Legs in their open position Your stage is now ready to raise.</p>	8		<p>FOR BOTH HEIGHT SETTINGS Add skirts, steps, rails and drapes if required.</p>
5		<p>Stand in the centre of the folded stage. Using the crossbar, gently pull the upper chrome leg outward and upward. Lower the stage wing until the D-Legs are on the floor. Repeat on the opposite side.</p>	9		<p>For maximum safety we recommend using ratchet straps to secure the stage segments together.</p>