












Drape and Telescopic Rigging Safe Operating Instructions

1		<p>Extend crossbars to correct width, making sure the crossbar nipple is securely emerging from its appropriate hole.</p>	7		<p>Beginning from the end, loosely hang the drapes by a few of the Velcro tabs.</p>
2		<p>Screw spigots into base plates. The centre hole in the baseplate is the safest. Ensure that the counter sunk holes face the floor so the bolt does not protrude.</p>	8		<p>Tie the Velcro ties, leaving approximately 150mm of drape width to hide your first upright. Keep the Velcro as tight as possible.</p>
3		<p>Slide uprights over spigots. When setting up a line of rigging it is easiest to lay out the crossbars on the floor so the row of bases can be located accurately.</p>	9		<p>Once at the end of the crossbar either continue onto the next crossbar or finish off by tying the drape around the upright.</p>
4		<p>Insert crossbar hooks into upright slots.</p>	10		<p>You are now ready to extend the uprights to the desired height. Extend one upright at a time in small increments, until you have reached the desired height.</p>
5		<p>Once crossbars have been inserted, you are now ready to loosely hang your drapes.</p>	11		<p>To release the lock, raise the inner pole slightly and lift the release ring. For safety hold the inner pole firmly while raising or lowering the height.</p>
6		<p>Carefully throw the drape over the crossbar to avoid lifting the drape.</p>			<p>The Staging Company recommends that rigging set above 5m have at least 1 x 10kg shotbag on the base.</p>